

TO VENTILATION SYSTEM PIPE
ZUM LÜFTUNGSSYSTEMROHR

THERMOCOUPLE
THERMOFÜHLER

FLOW ADJUSTMENT DAMPER
STRÖMUNGSEINTELLKLAPPE

ETNATHERM
VENTILATION
INSTALLATION

ETNATHERM
LÜFTUNG
INSTALLATION

SENSOR PANEL
SENSORFELD

Thermocouple Position
1500,00
Between 1200,00

Min: ϕ 101

ϕ 98

