



ETNATHERM
PADDLE BOX INSTALLATION

ETNATHERM
PADDELBOX-INSTALLATION



NOTE 1: WHEN THE FAN MOTOR WORKS FLUE DRIVING FILTER DEFINITELY DO NOT USE.

ANMERKUNG 1: WENN DER LÜFTERMOTOR FUNKTIONIERT RAUCHFAHRTFILTER DEFINITIV NICHT VERWENDEN.

FAN MOTOR
LÜFTERMOTOR